## 1-1.Key information

# Keys

The following keys are provided with the vehicle.



- Premium master key
- Master key
- 3 Valet key
- 4 Key number plate

#### n Alarm

Using the key or wireless remote control to lock the doors will set the alarm system.

# $\,\mathrm{n}\,$ When required to leave a key to the vehicle with a parking attendant

Lock the glove box as circumstances demand. ( $\rightarrow$ P. 210)

Carry the master key for your own use and provide the attendant with the valet key, as this key cannot be used to open the glove box.

## n Key number plate

Keep the plate in a safe place such as your wallet, not in the vehicle. In the event that a key is lost, a new key can be made at your Lexus dealer using the key number plate.  $(\rightarrow P. 344)$ 

# **⚠** NOTICE

### n To prevent key damage

Observe the following:

- 1 Do not subject the keys to strong shocks, expose them to high temperatures by placing them in direct sunlight, or get them wet.
- 1 Do not expose the keys to electromagnetic materials or attach any material that blocks electromagnetic waves to the key surface.
- 1 Do not disassemble the key.